



How to change front
brake discs on **Renault
Scenic 2** – replacement
guide

VIDEO TUTORIAL



i Important!

This replacement procedure can be used for:

RENAULT SCÉNIC II (JM0/1_) 2.0, RENAULT SCÉNIC II (JM0/1_) 1.6, RENAULT GRAND SCÉNIC II (JM0/1_) 1.6, RENAULT GRAND SCÉNIC II (JM0/1_) 2.0, RENAULT GRAND SCÉNIC II (JM0/1_) 1.5 dCi, RENAULT GRAND SCÉNIC II (JM0/1_) 1.9 dCi, RENAULT SCÉNIC II (JM0/1_) 2.0 16V Turbo, RENAULT SCÉNIC II (JM0/1_) 1.9 dCi, RENAULT SCÉNIC II (JM0/1_) 1.5 dCi, RENAULT SCÉNIC II (JM0/1_) 1.9 D, RENAULT SCÉNIC II (JM0/1_) 1.9 dCi 130

The steps may slightly vary depending on the car design.

REPLACEMENT: BRAKE DISCS – RENAULT SCENIC 2.

TOOLS YOU MIGHT NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Drive socket # 13
- Drive socket # 18
- Torx bit T30
- Wheel impact socket #19
- Brake caliper wind back tool
- Ratchet wrench
- Torque wrench
- Tap wrench
- Impact screwdriver
- Rubber mallet
- Crow bar
- Wheel chock

[BUY TOOLS](#)

Replacement: brake discs – Renault Scenic 2. AUTODOC experts recommend:

- Replace the brake disks on the car Renault Scenic 2 in complete set for each axis. Regardless of the state of components. This will ensure even braking.
- The replacement procedure is identical for both brake disks on the same axle.
- When changing the brake discs, always replace the brake pads.
- All work should be done with the engine stopped.

REPLACEMENT: BRAKE DISCS – RENAULT SCENIC 2. USE THE FOLLOWING PROCEDURE:

1

Open the bonnet. Unscrew the brake fluid reservoir cap.



2

Secure the wheels with chocks.




3

Loosen the wheel mounting bolts. Use wheel impact socket #19.




4

Raise the front of the car and secure on supports.



5

Unscrew the wheel bolts.




Replacement: brake discs – Renault Scenic 2. Tip:

- To avoid injury, hold up the wheel when unscrewing the bolts.

6

Remove the wheel.



7

Clean the brake caliper fasteners. Use a wire brush. Use WD-40 spray.



8

Unscrew the brake caliper fastening. Use a drive socket #13. Use a ratchet wrench.



9

Spread the brake pads. Use a crowbar.



10

Remove the brake caliper.



Replacement: brake discs – Renault Scenic 2. AUTODOC recommends:

- Tie the caliper to the suspension or to the body with a wire without disconnecting from the brake hose to prevent depressurization of the brake system.
- Make sure that the brake caliper is not hanging on the brake hose.
- Don't press the brake pedal after the brake caliper has been removed. As a result, the piston can fall out from the brake cylinder, and brake fluid leakage and depressurization of the system may occur.

11

Remove the brake pads. Use a crowbar.



12

Clean the brake caliper bracket fasteners. Use a wire brush. Use WD-40 spray.



13

Unscrew the caliper bracket fastening. Use a drive socket #18. Use a tap wrench.



14

Remove the caliper bracket.




15

Clean the brake disk surface. Use a wire brush. Use WD-40 spray.



16

Unscrew the brake disc fastening. Use Torx T30. Use an impact screwdriver.




Replacement: brake discs – Renault Scenic 2. Tip from AUTODOC:

- If necessary, use a rubber mallet.


17

Remove the brake disc. Use a rubber mallet.




18

Clean the hub. Use a wire brush. Treat the contacting surface. Use copper grease.




19

Install the brake disc.




20

Tighten the brake disc fastening. Use Torx T30. Use a torque wrench. Tighten it to 15 Nm torque.




21

Clean the brake caliper bracket from dirt and dust. Use a wire brush. Use WD-40 spray.




22

Install the brake caliper bracket.




23

Tighten the brake caliper bracket. Use a drive socket #18. Use a torque wrench. Tighten it to 105 Nm torque.



24

Install the brake pads.



25

Treat the brake caliper piston. Use a brake cleaner.



AUTODOC recommends:

- Replacement: brake discs – Renault Scenic 2. After applying the spray, wait a few minutes.

26

Press in the brake caliper piston. Use brake caliper wind back tool.




27

Install the brake caliper and fix it. Use a drive socket #13. Use a torque wrench. Tighten it to 32 Nm torque.



28

Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



29

Clean the brake disk surface. Use a brake cleaner.

Replacement: brake discs – Renault Scenic 2. Tip from AUTODOC experts:

- After applying the spray, wait a few minutes.

30

Install the wheel.




AUTODOC recommends:

- Important! Hold the wheel while screwing in the fastening bolts. Renault Scenic 2


31

Screw in the wheel bolts. Use wheel impact socket #19.



32

Lower the car and working in a cross order, tighten the wheel bolts. Use a torque wrench. Tighten it to 110 Nm torque.



Replacement: brake discs – Renault Scenic 2. AUTODOC experts recommend:

- Check the brake fluid level in the expansion tank and refill if necessary.

33

Tighten the brake fluid reservoir cap. Close the hood.



AUTODOC recommends:

- Renault Scenic 2 – Press the brake pedal several times with the engine shut down until you feel the resistance built up.

34

Remove the jacks and chocks.



WELL DONE! 

VIEW MORE TUTORIALS

AUTODOC – TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



+ AUTODOC

GET IT ON
Google Play

Download on the
App Store

Download

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BUY SPARE PARTS FOR RENAULT

BRAKE DISCS: A WIDE SELECTION

CHOOSE CAR PARTS FOR RENAULT SCENIC 2

BRAKE DISCS FOR RENAULT: BUY NOW

BRAKE DISCS FOR RENAULT SCENIC 2: THE BEST DEALS & OFFERS

DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC SE.